




O⁴xozone



User Manual

Please read the instruction carefully before use

CONTENTS

1. Safety Instructions	2
2. Technical Specifications	4
3. How To Set The Unit.....	5
3.1 Control Panel	5
3.2 Main Function.....	6
3.3 Home Position Adjustment	14
4. Control By Universal DMX Controller	17
4.1 DMX512 Connection	17
4.2 Address Setting	18
4.3 DMX 512 Configuration.....	18
5. Error Information	31
6. Troubleshooting	34
7. Fixture Cleaning	34

1. Safety Instructions



Please read the instruction carefully which includes important information about the installation, usage and maintenance.

WARNING

Please keep this User Guide for future consultation. If you sell the unit to another user, be sure that they also receive this instruction manual.

Important:

Damages caused by the disregard of this user manual are not subject to warranty. The dealer will not accept liability for any resulting defects or problems.

- Unpack and check carefully to ensure that there is no transportation damage before using the unit.
- This product is suitable for wet locations. Do not immerse in water.
- DO install and operate by qualified operator.
- DO NOT allow children to operate the fixture.
- Use safety chain when fixing the unit. Handle the unit by carrying its base instead of head only.
- The unit must be installed in a location with adequate ventilation, at least 50cm from adjacent surfaces.
- Be sure that no ventilation slots is blocked, otherwise the unit will be overheated.
- Before operation, ensure that you are connecting this product to the proper voltage in accordance with the specifications in this manual or on the product's specification label.
- It's important to ground the yellow/green conductor to earth in order to avoid electric shock.
- Minimum ambient temperature TA: 0°C. Maximum ambient temperature TA: 40°C. Do not operate this product at a lower or higher temperature.
- DO NOT connect the device to any dimmer pack.
- Keep flammable materials away from the fixture while operating to avoid fire hazard.
- Make sure the power cord is not crimped or damaged; replace it immediately if damaged.
- Unit's surface temperature may reach up to 75°C. DO NOT touch the housing bare-handed during its operation.
- Avoid any flammable liquids, water or metal from entering the unit. Once it happens, cut off the mains power immediately.

- DO NOT operate in a dirty or dusty environment. DO clean the fixture regularly.
- DO NOT touch any wire during operation as there might be a hazard of electric shock.
- Avoid entanglement of the power cord with other wires.
- The minimum distance to objects/surface must be more than 0.5 meters.
- Disconnect mains power before fuse replacement or servicing.
- Replace fuse only with the same type.
- In the event of serious operating problem, stop using the unit immediately.
- Never turn on and off the unit time after time.
- The housing, the lenses, or the ultraviolet filter must be replaced if they are visibly damaged.
- DO NOT open the housing as there are no user serviceable parts inside.
- DO NOT attempt to operate this unit if it becomes damaged. DO NOT attempt any repairs yourself. Repairs carried out by unskilled people can lead to damage or malfunction. Please contact the nearest authorized technical assistance center if needed.
- Disconnect this product from its power source before servicing.
- DO use the original packaging if the device is to be transported.
- Avoid direct eye exposure to the light source while the product is on.
- DO NOT operate this product if you see damage on the housing, shields, or cables. Have the damaged parts replaced by an authorized technician at once.

Installation:

The fixture should be fixed on the clamp. Always ensure that the unit is firmly fixed to avoid vibration and slipping off during operation. Ensure that the trussing or area of installation must be able to hold 10 times the weight without any deformation. Always install a safety cable that can hold at least 12 times the weight of the fixture when installing.

DO install and operate by qualified operator. It must be installed in a place where there is out of the reach of people.

2. Technical Specifications

Power Voltage:

100-240V~ 50/60Hz

Power Consumption:

990W

Light Source:

19x40W RGBW LED

Zoom Range:

6°~40°

Movement:

Pan: 540°

Tilt: 240°

Pan/Tilt Resolution: 16bit

Dimmer/Shutter:

0~100% smooth dimming, various strobe speed

Control:

DMX Channel: 17/21/86 Channels

Control Mode: DMX512, RDM

Firmware Upgrade: Update via DMX link or USB disk

Construction:

Display: Color display

Data In/Out: 5-pin IP XLR (3-pin IP XLR is optional)

Power In/Out: Waterproof Power Connector in/out

Protection Rating: IP66

Features:

Pixel control, outstanding color macro effect

Electronic linear zoom system

Integrated powerful beam and wash features

IP66 protection rating, can be used outdoors all year round


Dimension/Weight:

384x275x524mm, 24kgs


15"x10.8"x20.6" in, 53lbs

384x275x566mm, 25.8kgs (Version with clamp)

15"x10.8"x22.3" in, 57lbs (Version with clamp)




Photometric Diagram:



3. How To Set The Unit

3.1 Control Panel



1. Display: To show the various menus and the selected function

2. Button:

MENU	To enter into move backward or leave the menu
▲ UP	To go backward to move up in the menu
▼ DOWN	To go forward to move down in the menu
ENTER	To perform the desired functions

3. FIRMWARE UPGRADE: Used to upgrade fixture's firmware

4. DMX OUT:

For DMX512 link, use 5-pin XLR cable to link the next units (3-pin IP XLR cable is optional)

5. DMX IN:

For DMX512 link, use 5-pin XLR cable to link the unit and DMX controller (3-pin IP XLR is optional)

6. FUSE(T 15A):

To protect the unit from damage of over-voltage or short circuit

7. POWER IN:

To connect to supply power

8. POWER OUT:


To connect to the next fixture

3.2 Main Function

Turn on the unit, press the MENU button into menu mode, and press the UP/DOWN button until the required function is shown on the monitor. Select the function by pressing the ENTER button. Use the UP/DOWN button to choose the submenu, press the ENTER button to store and automatically return to the last menu. Press the MENU button or let the unit idle 30 seconds to exit menu mode.

The screen will be automatically locked if there is no operation for a long time, and can be unlocked by long-pressing the MENU button.

The main functions are shown below:



DMX Settings

To select **DMX Settings**, press the **ENTER** button to confirm, use the **UP/DOWN** button to select **DMX Address**, **DMX Channel Mode**, **No DMX Status** or **View DMX Value**.

DMX Address

To select **DMX Address**, press the **ENTER** button to confirm. Use the **UP/DOWN** button to adjust the address from **001** to **496/492/427**, press the **ENTER** button to store. Press the **MENU** button back to the last menu or let the unit idle 30 seconds to exit menu mode.

DMX Channel Mode

To select **DMX Channel Mode**, press the **ENTER** button to confirm. Use the **UP/DOWN** button to select **Mode1(17)**, **Mode2(21)** or **Mode3(86)**, press the **ENTER** button to store. Press the **MENU** button back to the last menu or let the unit idle 30 seconds to exit menu mode.

No DMX Status

To select **No DMX Status**, press the **ENTER** button to confirm. Use the **UP/DOWN** button to select **Blackout**(fixture blacks out if DMX signal stops), **Hold**(fixture continues to obey the last command it received Via DMX if DMX signal stops) or **Manual**(the fixture will automatically read the DMX value in the “Manual Test” menu for operation after selecting this mode), press the **ENTER** button to store. Press the **MENU** button back to the last menu or let the unit idle 30 seconds to exit menu mode.

View DMX Value

To select **View DMX Value**, press the **ENTER** button to confirm. Use the **UP/DOWN** button to view the DMX channel value. Press the **MENU** button back to the last menu or let the unit idle 30 seconds to exit menu mode.

Fixture Settings

To select **Fixture Settings**, press the **ENTER** button to confirm, use the **UP/DOWN** button to select **Pan Invert**, **Tilt Invert**, **P/T Feedback**, **Fan Mode**, **Dimmer Speed**, **Dimmer Curve** or **White Balance**.

Pan Invert

To select **Pan Invert**, press the **ENTER** button to confirm. Use the **UP/DOWN** button to select **No** (normal) or **Yes** (pan invert), press the **ENTER** button to store. Press the **MENU** button back to the last menu or let the unit idle 30 seconds to exit menu mode.

Tilt Invert

To select **Tilt Invert**, press the **ENTER** button to confirm. Use the **UP/DOWN** button to select **No** (normal) or **Yes** (tilt invert), press the **ENTER** button to store. Press the **MENU** button back to the last menu or let the unit idle 30 seconds to exit menu mode.

P/T Feedback

To select **P/T Feedback**, press the **ENTER** button to confirm. Use the **UP/DOWN** button to select **No** (Pan or tilt's position will not feedback while out of step) or **Yes** (Feedback while pan/tilt out of step), press the **ENTER** button to store. Press the **MENU** button back to the last menu or let the unit idle 30 seconds to exit menu mode.

Fan Mode

To select **Fan Mode**, press the **ENTER** button to confirm. Use the **UP/DOWN** button to select **Auto** or **Silent**, press the **ENTER** button to store. Press the **MENU** button back to the last menu or let the unit idle 30 seconds to exit menu mode.


Dimmer Speed

To select **Dimmer Speed**, press the **ENTER** button to confirm. Use the **UP/DOWN** button to select **Fast** or **Smooth**, press the **ENTER** button to store. Press the **MENU** button back to the last menu or let the unit idle 30 seconds to exit menu mode.


Dimmer Curve

To select **Dimmer Curve**, press the **ENTER** button confirm. Use the **DOWN/UP** button to select **Linear**, **Square law**, **Inv SQ law** or **S Curve**. Press the **MENU** button back to the last menu or let the unit idle 30 seconds to exit menu mode.


Dimmer Modes




Optically Linear



Square Law



Inverse Square Law



S-curve

Optically Linear: The increase in light intensity appears to be linear as DMX value is increased.

Square Law: Light intensity control is finer at low levels and coarser at high levels.

Inverse Square Law: Light intensity control is coarser at low levels and finer at high levels.

S-Curve: Light intensity control is finer at low levels and high levels and coarser at medium levels.

White Balance

To select **White Balance**, press the **ENTER** button to confirm. Use the **UP/DOWN** button to select **Red, Green, Blue, Red1, Green1, Blue1, Red2, Green2, Blue2.....Red19, Green19, Blue19**, press the **ENTER** button to store. Use the **UP/DOWN** button to adjust the value from **125** to **255**, press the **ENTER** button to store. Press the **MENU** button back to the last menu or let the unit idle 30 seconds to exit menu mode.

Display Settings

To select **Display Settings**, press the **ENTER** button to confirm, use the **UP/DOWN** button to select **Display Inverse, Backlight Intensity, Temperature Unit or Language**.

Display Inverse

Select **Display Inverse**, press the **ENTER** button to confirm, present mode will blink on the display, use the **UP/DOWN** button to select **No** (normal display) or **Yes** (inverse display), press the **ENTER** button to store. Press the **MENU** button back to the last menu or let the unit idle 30 seconds to exit menu mode.

Backlight Intensity

Select **Backlight Intensity**, press the **ENTER** button to confirm, present mode will blink on the display, press the **ENTER** button to confirm, then use the **UP/DOWN** button to adjust the value **001-010**, press the **ENTER** button to store. Press the **MENU** button back to the last menu or let the unit idle 30 seconds to exit menu mode.

Temperature Unit

Select **Temperature Unit**, press the **ENTER** button to confirm, present mode will blink on the display, use the **UP/DOWN** button to select **°C** or **°F**, press the **ENTER** button to store. Press the **MENU** button back to the last menu or let the unit idle 30 seconds to exit menu mode.

Language

Select **Language**, press the **ENTER** button to confirm, present mode will blink on the display, use the **UP/DOWN** button to select **English** or **Chinese**, press the **ENTER** button to store. Press the **MENU** button back to the last menu or let the unit idle 30 seconds to exit menu mode.

Fixture Test

To select **Fixture Test**, press the **ENTER** button to confirm, use the **UP/DOWN** button to select **Auto Test** or **Manual Test**.

Auto Test

Select **Auto Test**, press the **ENTER** button to confirm, the unit will run built-in programs to automatically test itself. Press the **MENU** button back to the last menu or exit menu mode after auto test.

Manual Test

Select **Manual Test**, press the **ENTER** button to confirm, the present channel will show on the display, use the **UP/DOWN** button to select channel, press the **ENTER** button to confirm, then use the **UP/DOWN** button to adjust the value, press the **ENTER** button to store, the fixture will run as the channel value indicates. Press the **MENU** button back to the last menu or exit menu mode idling 30 seconds.

(The fixture will return to the previous DMX state after exiting Manual Test menu and the Manual Test parameters will be automatically saved after power off and restart.)

Fixture Information

To select **Fixture Information**, press the **ENTER** button to confirm, use the **UP/DOWN** button to select **Fixture Use Hour**, **LED Use Hour**, **Temperature**, **Humidity**, **USB Upgrade File**, **Fan State**, **Firmware Version**, **RDM UID** or **Error Logs**.

Fixture Use Hour

Select **Fixture Use Hour**, press the **ENTER** button to confirm, fixture use hour will show on the display, press the **MENU** button to exit.

LED Use Hour

To select **LED Use Hour**, press the **ENTER** button to confirm, use the **UP/DOWN** button to select **Total LED Hour**, **LED On Hour** or **LED Hours Reset**, press the **ENTER** button to store. Use the **UP/DOWN** button to select **LED Hours Reset**, press the **ENTER** button to confirm, use the **UP/DOWN** button to set the password **050** to reset the LED hours, press the **ENTER** button to store, press the **MENU** button to exit.

Temperature

Select **Temperature**, press the **ENTER** button to confirm, fixture temperature will show on the display, press the **MENU** button to exit.

Humidity

Select **Humidity**, press the **ENTER** button to confirm, fixture humidity will show on the display, press the **MENU** button to exit.

USB Upgrade File

Select **USB Upgrade File**, press the **ENTER** button to confirm, USB upgrade file will show on the display, press the **MENU** button to exit.

Fan State

Select **Fan State**, press the **ENTER** button to confirm, fan state will show on the display, press the **MENU** button to exit.

Firmware Version

Select **Firmware Version**, press the **ENTER** button to confirm, firmware version will show on the display, press the **MENU** button back to exit.

RDM UID

Select **RDM UID**, press the **ENTER** button to confirm, RDM UID will show on the display, press the **MENU** button back to exit.

Error Logs

Select **Error Logs**, press the **ENTER** button to confirm. Use the **UP/DOWN** button to select **Fixture Errors** or **Reset Error Log**, press the **ENTER** button to store. Select **Reset Error Log**, press the **ENTER** button to confirm. Use the **UP/DOWN** button to select **No** or **Yes**, press the **ENTER** button to store. Select **Yes**, press the **ENTER** button to confirm. Use the **UP/DOWN** button to set the password **050**, press the **ENTER** button to store. Press the **MENU** button back to the last menu or let the unit idle 30 seconds to exit menu mode.

Reset Functions

To select **Reset Functions**, press the **ENTER** button to confirm, use the **UP/DOWN** button to select **Pan/Tilt Reset**, **Zoom Reset** or **All Reset**.

Pan/Tilt Reset

To select **Pan/Tilt Reset**, press the **ENTER** button to confirm, use the **UP/DOWN** button to select **No**(normal) or **Yes** (the unit will run built-in program to reset pan and tilt to their home positions), press the **ENTER** button to store. Press the **MENU** button to exit.

Zoom Reset

To select **Zoom Reset**, press the **ENTER** button to confirm, use the **UP/DOWN** button to select **No** or **Yes**(the unit will run built-in program to reset zoom to its home position), press the **ENTER** button to store. Press the **MENU** button to exit.

All Reset

To select **All Reset**, press the **ENTER** button to confirm, use the **UP/DOWN** button to select **No** or **Yes**(the unit will run built-in program to reset all motors to their home positions), press **ENTER** button to store. Press the **MENU** button to exit.

Special Functions

Factory Restore

Select **Factory Restore**, press the **ENTER** button to confirm, use the **UP/DOWN** button to select **No** (normal) or **Yes** (the fixture will reset to factory settings), press **ENTER** button to store. Press the **MENU** button to exit.

RDM FUNCTIONS

Select the MANUFACTURER menu to display the manufacturer of the fixture.

Select the SOFTWARE VERSION menu and the program version number of the fixture will be displayed.

Select the DMX START ADDRESS menu to change the DMX 512 address (001-512).

Select the DEVICE MODEL DESCRIPTION menu to display the model of the fixture.

Select the DEVICE LABEL menu to change the model of the fixture.

Select the DMX PERSONALITY menu to set the channel mode of the fixture (17/21/86 channel).

Select the DMX PERSONALITY DESCRIPTION menu to display the current channel mode of the fixture.

Select the DEVICE HOURS menu to display the running time of the fixture.


Select the PAN INVERT menu and the fixture will run the pan invert mode.

Select the TILT INVERT menu and the fixture will run the tilt invert mode.

Select the RESET DEVICE menu, the WARM RESET/COLD RESET option will be displayed. When WARM RESET is selected, the fixture will start a warm reset, and exit when COLD RESET is selected.

3.3 Home Position Adjustment

Press the MENU button into menu mode, then press the ENTER button for about 3 seconds into offset mode to adjust the home position. Select the function by pressing the ENTER button. Use the UP/DOWN button to choose the submenu, press the ENTER button to store and automatically return to the last menu. Press MENU button to exit.



Pan

Enter offset mode, Select **Pan**, press the **ENTER** button to confirm, the present position will blink on the display, use the **UP/DOWN** button to offset the value from -128 to 127, press the **ENTER** button to store. Press the **MENU** button to exit.

Tilt

Enter offset mode, Select **Tilt**, press the **ENTER** button to confirm, the present position will blink on the display, use the **UP/DOWN** button to offset the value from -128 to 127, press the **ENTER** button to store. Press the **MENU** button to exit.

Zoom

Enter offset mode, Select **Zoom**, press the **ENTER** button to confirm, the present position will blink on the display, use the **UP/DOWN** button to offset the value from -128 to 127, press the **ENTER** button to store. Press the **MENU** button to exit.

Red1

Enter offset mode, Select **Red1**, press the **ENTER** button to confirm, the present position will blink on the display, use the **UP/DOWN** button to offset the value from 20 to 1000, press the **ENTER** button to store. Press the **MENU** button to exit.

Red2

Enter offset mode, Select **Red2**, press the **ENTER** button to confirm, the present position will blink on the display, use the **UP/DOWN** button to offset the value from 20 to 1000, press the **ENTER** button to store. Press the **MENU** button to exit.

.....

Red19

Enter offset mode, Select **Red19**, press the **ENTER** button to confirm, the present position will blink on the display, use the **UP/DOWN** button to offset the value from 20 to 1000, press the **ENTER** button to store. Press the **MENU** button to exit.

Green1

Enter offset mode, Select **Green1**, press the **ENTER** button to confirm, the present position will blink on the display, use the **UP/DOWN** button to offset the value from 20 to 1000, press the **ENTER** button to store. Press the **MENU** button to exit.

Green2

Enter offset mode, Select **Green2**, press the **ENTER** button to confirm, the present position will blink on the display, use the **UP/DOWN** button to offset the value from 20 to 1000, press the **ENTER** button to store. Press the **MENU** button to exit.

.....

Green19

Enter offset mode, Select **Green19**, press the **ENTER** button to confirm, the present position will blink on the display, use the **UP/DOWN** button to offset the value from 20 to 1000, press the **ENTER** button to store. Press the **MENU** button to exit.

Blue1

Enter offset mode, Select **Blue1**, press the **ENTER** button to confirm, the present position will blink on the display, use the **UP/DOWN** button to offset the value from 20 to 1000, press the **ENTER** button to store. Press the **MENU** button to exit.

Blue2

Enter offset mode, Select **Blue2**, press the **ENTER** button to confirm, the present position will blink on the display, use the **UP/DOWN** button to offset the value from 20 to 1000, press the **ENTER** button to store. Press the **MENU** button to exit.

.....

Blue19

Enter offset mode, Select **Blue19**, press the **ENTER** button to confirm, the present position will blink on the display, use the **UP/DOWN** button to offset the value from 20 to 1000, press the **ENTER** button to store. Press the **MENU** button to exit.

White1

Enter offset mode, Select **White1**, press the **ENTER** button to confirm, the present position will blink on the display, use the **UP/DOWN** button to offset the value from 20 to 1000, press the **ENTER** button to store. Press the **MENU** button to exit.

White2

Enter offset mode, Select **White2**, press the **ENTER** button to confirm, the present position will blink on the display, use the **UP/DOWN** button to offset the value from 20 to 1000, press the **ENTER** button to store. Press the **MENU** button to exit.


.....

White19

Enter offset mode, Select **White19**, press the **ENTER** button to confirm, the present position will blink on the display, use the **UP/DOWN** button to offset the value from 20 to 1000, press the **ENTER** button to store. Press the **MENU** button to exit.

4. Control By Universal DMX Controller

4.1 DMX512 Connection



1. At last unit, the DMX cable has to be terminated with a terminator. Solder a 120-ohm 1/4W resistor between pin 2(DMX-) and pin 3(DMX+) into a 3-pin XLR-plug and plug it in the DMX-output of the last unit.
2. Connect the unit together in a “daisy chain” by XLR plug cable from the output of the unit to the input of the next unit. The cable can only be used in series and cannot be connected in parallel. DMX 512 is a very high-speed signal. Inadequate or damaged cables, soldered joints or corroded connectors can easily distort the signal and shut down the system.
3. The DMX output and input connectors are pass-through to maintain the DMX circuit, when one of the units’ power is disconnected.
4. Each lighting unit needs to have a DMX address to receive the data by the controller. The address number is between 1-512.
5. The end of the DMX 512 system should be terminated to reduce signal errors.
6. 3 pin XLR connectors are more popular than 5 pins XLR.
 - 3 pin XLR: Pin 1: GND, Pin 2: Negative signal (-), Pin 3: Positive signal (+)
 - 5 pin XLR: Pin 1: GND, Pin 2: Negative signal (-), Pin 3: Positive signal (+), Pin4, Pin5 not used.

4.2 Address Setting

If you use a universal DMX controller to control the units, you have to set DMX address from 1 to 512 so that the units can receive DMX signal.

Press the MENU button to enter menu mode, select DMX Settings, press the ENTER button to confirm, use the UP/DOWN button to select DMX Address, press the ENTER button to confirm, the present address will blink in the display, use the UP/DOWN button to adjust the address from 001 to 512, press the ENTER button to store. Press the MENU button back to the last menu or let the unit idle 30 seconds to exit menu mode.

Please refer to the following diagram to address your DMX512 channel for the first 4 units.

Channel mode	Unit 1 Address	Unit 2 Address	Unit 3 Address	Unit 4 Address
17 channels	1	18	35	52
21 channels	1	22	43	64
86 channels	1	87	173	259

4.3 DMX 512 Configuration

Please control the fixture by referring to the configurations below

Attentions:

1. The unit will maintain the last condition until reset if you cut-off the DMX signal.
2. For the channel Function, keep the value for about 3 seconds, then the corresponding function will take into effect.

17 Channels (Mode 1):

CHANNEL	VALUE	FUNCTION
1	000-255	PAN 0°→540°
2	000-255	PAN FINE
3	000-255	TILT 0°→240°
4	000-255	TILT FINE
5	000-255	ZOOM 6°→40°

6	000-079	FUNCTION
	080-089	Null
	090-099	Dimmer Smooth
	100-139	Dimmer Fast
	140-149	Null
	150-159	Pan/Tilt Reset
	160-199	Zoom Reset
	200-209	Null
7	210-255	Reset All
		Null
8	000-255	DIMMER 0%→100%
9	000-255	DIMMER FINE
10	000-007	STROBE
	008-015	Close
	016-131	Open
	032-139	Strobe effect slow to fast
	140-181	Open
	182-189	Fast close slow open slow to fast
	190-231	Open
	232-239	Fast open slow close slow to fast
11	240-247	Open
	248-255	Random strobe effect slow to fast
12	000-255	Open
13	000-255	RED 0%→100%
14	000-255	GREEN 0%→100%
15	000-255	BLUE 0%→100%
16	000-255	WHITE 0%→100%
17	000	LINEAR CTO (8000K-2500K)
	001-004	Null
	005-009	8000K
	010-013	7900K
	014-018	7800K
	019-022	7700K
	023-027	7600K
	028-031	7500K
	032-036	7400K
	037-040	7300K
	041-045	7200K
	046-049	7100K
		7000K

	050-054	6900K
	055-058	6800K
	059-063	6700K
	064-067	6600K
	068-072	6500K
	073-076	6400K
	077-081	6300K
	082-085	6200K
	086-090	6100K
	091-094	6000K
	095-099	5900K
	100-103	5800K
	104-108	5700K
	109-112	5600K
	113-117	5500K
	118-121	5400K
	122-126	5300K
	127-130	5200K
	131-135	5100K
	136-139	5000K
	140-144	4900K
	145-148	4800K
	149-153	4700K
	154-157	4600K
	158-162	4500K
	163-166	4400K
	167-171	4300K
	172-175	4200K
	176-180	4100K
	181-184	4000K
	185-189	3900K
	190-193	3800K
	194-198	3700K
	199-202	3600K
	203-207	3500K
	208-211	3400K
	212-216	3300K
	217-220	3200K
	221-225	3100K
	226-229	3000K
	230-234	2900K
	235-238	2800K
	239-243	2700K
	244-247	2600K
	248-255	2500K
15	000-007	COLOR MACRO (32 COLOR) NULL

	008-011 012-015 016-019 020-023 024-027 028-031 032-035 036-039 040-043 044-047 048-051 052-055 056-059 060-063 064-067 068-071 072-075 076-079 080-083 084-087 088-091 092-095 096-099 100-103 104-107 108-111 112-115 116-119 120-123 124-127 128-131 132-135 136-165 166-195 196-205 206-215 216-225 226-235 236-245 246-255	Color1 Color2 Color3 Color4 Color5 Color6 Color7 Color8 Color9 Color10 Color11 Color12 Color13 Color14 Color15 Color16 Color17 Color18 Color19 Color20 Color21 Color22 Color23 Color24 Color25 Color26 Color27 Color28 Color29 Color30 Color31 Color32 Rotate CW Fast → Slow Rotate CCW Slow → Fast Red → Green Red → Blue Red → White Green → Blue Green → White Blue → White
16	000 001 002-245 246 247 248	PIXEL (See “Pixel of 16 CH” in detail) No Function Open Pattern1-244 Built-in Mode1 Built-in Mode2 Built-in Mode3

	249 250 251-255	One light is on randomly Two lights are on randomly Open
17	000-031 032-091 092-101 102-161 162-255	PIXEL ROTATION NULL Rotate CW Fast → Slow NULL Rotate CCW Slow → Fast NULL

21 Channels (Mode 2):

CHANNEL	VALUE	FUNCTION
1	000-255	PAN 0°→540°
2	000-255	PAN FINE
3	000-255	TILT 0°→240°
4	000-255	TILT FINE
5	000-255	ZOOM 6°→40°
6	000-079 080-089 090-099 100-139 140-149 150-159 160-199 200-209 210-255	FUNCTION Null Dimmer Smooth Dimmer Fast Null Pan/Tilt Reset Zoom Reset Null Reset All Null
7	000-255	DIMMER 0%→100%
8	000-255	DIMMER FINE
9	000-007 008-015 016-131 032-139 140-181 182-189 190-231	STROBE Close Open Strobe effect slow to fast Open Fast close slow open slow to fast Open Fast open slow close slow to fast

	232-239 240-247 248-255	Open Random strobe effect slow to fast Open
10	000-255	RED 0%→100%
11	000-255	GREEN 0%→100%
12	000-255	BLUE 0%→100%
13	000-255	WHITE 0%→100%
14	000-255	RED2 0%→100%
15	000-255	GREEN2 0%→100%
16	000-255	BLUE2 0%→100%
17	000-255	WHITE2 0%→100%
18	000-255	RED3 0%→100%
19	000-255	GREEN3 0%→100%
20	000-255	BLUE3 0%→100%
21	000-255	WHITE3 0%→100%

86 Channels (Mode 3):

CHANNEL	VALUE	FUNCTION
1	000-255	PAN 0°→540°
2	000-255	PAN FINE
3	000-255	TILT 0°→240°
4	000-255	TILT FINE
5	000-255	PAN/TILT SPEED Fast→Slow
6	000-255	ZOOM 6°→40°

























































































7	000-007	STROBE
	008-015	Close
	016-131	Open
	032-139	Strobe effect slow to fast
	140-181	Open
	182-189	Fast close slow open slow to fast
	190-231	Open
	232-239	Fast open slow close slow to fast
	240-247	Open
	248-255	Random strobe effect slow to fast
8	000-255	DIMMER
		0%→100%
9	000-255	DIMMER FINE
10	000-255	RED1
		0%→100%
11	000-255	GREEN1
		0%→100%
12	000-255	BLUE1
		0%→100%
13	000-255	WHITE1
		0%→100%
14	000-255	RED2
		0% ~ 100%
15	000-255	GREEN2
		0%→100%
16	000-255	BLUE2
		0%→100%
17	000-255	WHITE2
		0%→100%
18	000-255	RED3
		0%→100%
19	000-255	GREEN3
		0%→100%
20	000-255	BLUE3
		0%→100%
21	000-255	WHITE3
		0%→100%
22	000-255	RED4
		0%→100%
23	000-255	GREEN4
		0%→100%
24	000-255	BLUE4
		0%→100%

























































































25	000-255	WHITE4 0%→100%
26	000-255	RED5 0%→100%
27	000-255	GREEN5 0%→100%
28	000-255	BLUE5 0%→100%
29	000-255	WHITE5 0%→100%
30	000-255	RED6 0%→100%
31	000-255	GREEN6 0%→100%
32	000-255	BLUE6 0%→100%
33	000-255	WHITE6 0%→100%
34	000-255	RED7 0%→100%
35	000-255	GREEN7 0%→100%
36	000-255	BLUE7 0%→100%
37	000-255	WHITE7 0%→100%
38	000-255	RED8 0%→100%
39	000-255	GREEN8 0%→100%
40	000-255	BLUE8 0%→100%
41	000-255	WHITE8 0%→100%
42	000-255	RED9 0%→100%
43	000-255	GREEN9 0%→100%
44	000-255	BLUE9 0%→100%
45	000-255	WHITE9 0%→100%
46	000-255	RED10 0%→100%



















































































47	000-255	GREEN10 0%→100%
48	000-255	BLUE10 0%→100%
49	000-255	WHITE10 0%→100%
50	000-255	RED11 0%→100%
51	000-255	GREEN11 0%→100%
52	000-255	BLUE11 0%→100%
53	000-255	WHITE11 0%→100%
54	000-255	RED12 0%→100%
55	000-255	GREEN12 0%→100%
56	000-255	BLUE12 0%→100%
57	000-255	WHITE12 0%→100%
58	000-255	RED13 0%→100%
59	000-255	GREEN13 0%→100%
60	000-255	BLUE13 0%→100%
61	000-255	WHITE13 0%→100%
62	000-255	RED14 0%→100%
63	000-255	GREEN14 0%→100%
64	000-255	BLUE14 0%→100%
65	000-255	WHITE14 0%→100%
66	000-255	RED15 0%→100%
67	000-255	GREEN15 0%→100%
68	000-255	BLUE15 0%→100%

69	000-255	WHITE15 0%→100%
70	000-255	RED16 0%→100%
71	000-255	GREEN16 0%→100%
72	000-255	BLUE16 0%→100%
73	000-255	WHITE16 0%→100%
74	000-255	RED17 0%→100%
75	000-255	GREEN17 0%→100%
76	000-255	BLUE17 0%→100%
77	000-255	WHITE17 0%→100%
78	000-255	RED18 0%→100%
79	000-255	GREEN18 0%→100%
80	000-255	BLUE18 0%→100%
81	000-255	WHITE18 0%→100%
82	000-255	RED19 0%→100%
83	000-255	GREEN19 0%→100%
84	000-255	BLUE19 0%→100%
85	000-255	WHITE19 0%→100%
86	000-079 080-089 090-099 100-139 140-149 150-159 160-199 200-209 210-255	FUNCTION NULL Dimmer Smooth Dimmer Fast NULL Pan Tilt Reset Zoom Reset NULL Reset All NULL

Pixel of 16 CH:

 Value : 000	 Value : 001	 Value : 002	 Value : 003	 Value : 004	 Value : 005	 Value : 006	 Value : 007
 Value : 008	 Value : 009	 Value : 010	 Value : 011	 Value : 012	 Value : 013	 Value : 014	 Value : 015
 Value : 016	 Value : 017	 Value : 018	 Value : 019	 Value : 020	 Value : 021	 Value : 022	 Value : 023
 Value : 024	 Value : 025	 Value : 026	 Value : 027	 Value : 028	 Value : 029	 Value : 030	 Value : 031
 Value : 032	 Value : 033	 Value : 034	 Value : 035	 Value : 036	 Value : 037	 Value : 038	 Value : 039
 Value : 040	 Value : 041	 Value : 042	 Value : 043	 Value : 044	 Value : 045	 Value : 046	 Value : 047
 Value : 048	 Value : 049	 Value : 050	 Value : 051	 Value : 052	 Value : 053	 Value : 054	 Value : 055
 Value : 056	 Value : 057	 Value : 058	 Value : 059	 Value : 060	 Value : 061	 Value : 062	 Value : 063
 Value : 064	 Value : 065	 Value : 066	 Value : 067	 Value : 068	 Value : 069	 Value : 070	 Value : 071
 Value : 072	 Value : 073	 Value : 074	 Value : 075	 Value : 076	 Value : 077	 Value : 078	 Value : 079
 Value : 080	 Value : 081	 Value : 082	 Value : 083	 Value : 084	 Value : 085	 Value : 086	 Value : 087

 Value: 088	 Value: 089	 Value: 090	 Value: 091	 Value: 092	 Value: 093	 Value: 094	 Value: 095
 Value: 096	 Value: 097	 Value: 098	 Value: 099	 Value: 100	 Value: 101	 Value: 102	 Value: 103
 Value: 104	 Value: 105	 Value: 106	 Value: 107	 Value: 108	 Value: 109	 Value: 110	 Value: 111
 Value: 112	 Value: 113	 Value: 114	 Value: 115	 Value: 116	 Value: 117	 Value: 118	 Value: 119
 Value: 120	 Value: 121	 Value: 122	 Value: 123	 Value: 124	 Value: 125	 Value: 126	 Value: 127
 Value: 128	 Value: 129	 Value: 130	 Value: 131	 Value: 132	 Value: 133	 Value: 134	 Value: 135
 Value: 136	 Value: 137	 Value: 138	 Value: 139	 Value: 140	 Value: 141	 Value: 142	 Value: 143
 Value: 144	 Value: 145	 Value: 146	 Value: 147	 Value: 148	 Value: 149	 Value: 150	 Value: 151
 Value: 152	 Value: 153	 Value: 154	 Value: 155	 Value: 156	 Value: 157	 Value: 158	 Value: 159
 Value: 160	 Value: 161	 Value: 162	 Value: 163	 Value: 164	 Value: 165	 Value: 166	 Value: 167
 Value: 168	 Value: 169	 Value: 170	 Value: 171	 Value: 172	 Value: 173	 Value: 174	 Value: 175

 Value: 176	 Value: 177	 Value: 178	 Value: 179	 Value: 180	 Value: 181	 Value: 182	 Value: 183
 Value: 184	 Value: 185	 Value: 186	 Value: 187	 Value: 188	 Value: 189	 Value: 190	 Value: 191
 Value: 192	 Value: 193	 Value: 194	 Value: 195	 Value: 196	 Value: 197	 Value: 198	 Value: 199
 Value: 200	 Value: 201	 Value: 202	 Value: 203	 Value: 204	 Value: 205	 Value: 206	 Value: 207
 Value: 208	 Value: 209	 Value: 210	 Value: 211	 Value: 212	 Value: 213	 Value: 214	 Value: 215
 Value: 216	 Value: 217	 Value: 218	 Value: 219	 Value: 220	 Value: 221	 Value: 222	 Value: 223
 Value: 224	 Value: 225	 Value: 226	 Value: 227	 Value: 228	 Value: 229	 Value: 230	 Value: 231
 Value: 232	 Value: 233	 Value: 234	 Value: 235	 Value: 236	 Value: 237	 Value: 238	 Value: 239
 Value: 240	 Value: 241	 Value: 242	 Value: 243	 Value: 244	 Value: 245		
 Value: 246				 Value: 247			
 Value: 248			 Value: 249 Randomly	 Value: 250 Randomly	 Value: 251-255		

5. Error Information

Error codes are shown continuously in the display when the fixture fails and they will not disappear until the fixture is repaired.

1. Pan Reset Error

Check whether the position of the pan where the magnet is installed falls off or is damaged.

Check whether there are obstacles in the pan operating range.

Check whether the Hall element on the pan is damaged.

Check whether the lead connecting the Hall element on the pan and the PCB board is in poor contact or disconnected.

Check whether the motor on the pan is damaged.

Check whether the related circuit of the motor drive board on the pan is damage.

2. Pan Encode Error

Check whether the encoder on the pan is damaged.

Check whether the lead connecting the encoder on the pan and the PCB board is in poor contact or disconnected.

3. Tilt Reset Error

Check whether the position of the tilt where the magnet is installed falls off or is damaged.

Check whether there are obstacles in the tilt operating range.

Check whether the Hall element on the tilt is damaged.

Check whether the lead connecting the Hall element on the tilt and the PCB board is in poor contact or disconnected.

Check whether the motor on the tilt is damaged.

Check whether the related circuit of the motor drive board on the tilt is damage.

4. Tilt Encode Error

Check whether the encoder on the tilt is damaged.

Check whether the lead connecting the encoder on the tilt and the PCB board is in poor contact or disconnected.

5. CPU-B/C/D/E/F/G/H Error

Check whether the 485 (DATA) leads on the PCB board are installed in place or disconnected.

Check whether the related 485 (DATA) signal circuit on the PCB board is damaged.

6. BaseFan1/2 cannot start

Check whether the fan is not running.

Check whether the fan leads are installed in place or disconnected.

Check whether the fan is damaged.

Check whether there are obstacles in the fan operating range.

7. BaseFan1/2 cannot stop

Check whether the fan circuit on the motherboard breaks down.

Check whether the component is damaged.

8. LEDFan1/2 cannot start

Check whether the fan is not running.

Check whether the fan leads are installed in place or disconnected.

Check whether the fan is damaged.

Check whether there are obstacles in the fan operating range.

9. LEDFan1/2 cannot stop

Check whether the fan circuit on the motherboard breaks down.

Check whether the component is damaged.

10. LEDFan1/2 speed too fast

Check whether the fan is out of order.

Check whether the fan circuit on the motherboard breaks down.

11. LEDFan1/2 speed too slow

Check whether the fan is out of order.

Check whether there are obstacles in the fan operating range.

12. HeadFan1/2/3 cannot start

Check whether the fan is not running.

Check whether the fan leads are installed in place or disconnected.

Check whether the fan is damaged.

Check whether there are obstacles in the fan operating range.

13. HeadFan1/2/3 cannot stop

Check whether the fan circuit on the motherboard breaks down.

Check whether the component is damaged.

14. HeadFan1/2/3 speed too fast

Check whether the fan is out of order.

Check whether the fan circuit on the motherboard breaks down.

15. HeadFan1/2/3 speed too slow

Check whether the fan is out of order.

Check whether there are obstacles in the fan operating range.

16. ArmFan2 cannot start

Check whether the fan is not running.

Check whether the fan leads are installed in place or disconnected.

Check whether the fan is damaged.

Check whether there are obstacles in the fan operating range.

17. ArmFan2 cannot stop

Check whether the fan circuit on the motherboard breaks down.

Check whether the component is damaged.

18. Led Temp. Too High

Check if the fan is working properly.

Check if the fan speed is normal.

Check if the ambient temperature is abnormal.

6. Troubleshooting

Following are a few common problems that may occur during operation. Here are some suggestions for troubleshooting:

A. The unit does not work, no light and the fan does not work

1. Check the connected power and the main fuse.
2. Measure the voltage.
3. Check the power indicator to see whether it can be lit up or not.

B. Not responding to the DMX controller

1. Check whether the DMX connectors and the DMX cables are connected correctly.
2. Check whether the DMX address is correctly set.
3. If the intermittent DMX signal problem occurs, check whether the XLR socket and the signal cable are well connected.
4. Try it with another DMX controller.
5. Check whether the DMX cables run near or alongside to the high-voltage cables, which may damage or interfere with the signal circuit.

C. One of the channels is not working well

1. The stepper motor might be damaged or the cable connected to the PCB might be broken.
2. The motor's drive IC on the PCB might be out of condition.

7. Fixture Cleaning

It is absolutely essential that the fixture is kept clean to ensure the maximum light-output and allow the fixture to function reliably throughout its life. The fixture must be cleaned regularly to avoid dust, dirt and smoke-fluid residues building up on or within the fixture. The cleaning frequency depends on the application environment. Clean the fixture immediately if the dust enters it to avoid damage to the optical lens due to excessive dust.

- A soft lint-free cloth moistened with any good glass cleaning fluid is recommended, under no circumstances should solvents be used.
- Always dry the parts carefully.
- Clean the external optical lens at least every 20 days.

Innovation, Quality, Performance