



## Wichtiger Bedienungshinweis bei Erstinbetriebnahme.

Das Gerät startet, werksmäßig im Dimmer-Modus. In diesem Modus ist nur der Menüpunkt „RUNDMODE“ zugänglich.  
Sobald ein anderer Betriebsmodus als „DMMR“ gewählt wird sind sämtliche Menüs zugänglich.

Um den Zoom zu justieren wenn das Gerät per Dimmerpack angesteuert wird, ändern Sie den Betriebsmodus auf „DMX“ und stellen Sie den gewünschten Zoom-Wert ein. Ändern Sie nach der Justage den Betriebsmodus wieder auf „DMMR“. Die eingestellten Werte bleiben auch Verlust der Netzspannung eingestellt.

## Important Operationinformation for startup

This fixture starts by default in „DMMR“ (Dimmer) operation mode. In this mode the access to all menus except for „RUNMODE“ are locked. If you change the operation mode to DMX or Slave, full access to all menus is given.

To adjust the Zoom while operating via dimmerpack change the operation mode to „DMX“. Adjust the zoom value in the static menu. Than change the operation mode back to „DMMR“. The zoom value is stored and available even after power break.