

# **EXPOLITE**

## **TourLED MC 120 MKII**



### **DMX-Chart**

## **Kanalbelegung DMX 512**

Version 2

## HSIC ( 8 Kanal )

DMX Kanal	Wert	Funktion
<b>1</b>	000 – 255	<b>INTENSITY</b>
<b>2</b>	000 – 255	<b>HUE</b>
<b>3</b>	000 – 255	<b>HUE FINE</b>
<b>4</b>	000 – 255	<b>SATURATION</b>
<b>5</b>	000 – 009 010 - 024 025 - 039 040 - 054 055 - 069 070 - 084 085 - 099 100 - 114 115 - 129 130 - 144 145 - 159 160 - 174 175 - 189 190 - 204 205 - 245 255	<b>CCT</b> NO FUNCTION 1800K – 2199K 2200K – 2699K 2700K – 2999K 3000K – 3199K 3200K – 3999K 4000K – 4499K 4500K – 4999K 5000K – 5599K 5600K – 5999K 6000K – 6499K 6500K – 6999K 7000K – 7999K 8000K – 8999K 9000K – 9999K 10000K
<b>6</b>	000 – 009 010 – 099 100 – 109 110 – 179 180 – 189 190 – 255	<b>STROBE</b> NO FUNCTION STROBE SLOW TO FAST NO FUNCTION THUNDER STROBE NO FUNCTION RANDOM STROBE
<b>7</b>	0 - 255	<b>ZOOM</b>
<b>8</b>	000 – 010 011 – 100 101 – 110 111 – 120 121 – 150 151 – 160 161 – 170 171 – 180	<b>CONTROL ( execute after 3 sec. )</b> NO FUNCTION RESERVED DIMMER OFF DIMMER DIM4 RESERVED 1200Hz 2400Hz 4000Hz

	181 – 190	6000Hz
	191 – 200	25000Hz
	201 – 210	ALL RESET
	211 – 220	ZOOM RESET
	221 – 255	RESERVED

### SSP ( 8 Kanal )

DMX Kanal	Wert	Funktion
<b>1</b>	000 – 255	<b>MASTER DIMMER</b>
<b>2</b>	000 – 255	<b>RED</b>
<b>3</b>	000 – 255	<b>GREEN</b>
<b>4</b>	000 – 255	<b>BLUE</b>
<b>5</b>	000 – 255	<b>WHITE</b>
<b>6</b>	000 – 009 010 – 099 100 – 109 110 – 179 180 – 189 190 – 255	<b>STROBE</b> NO FUNCTION STROBE SLOW TO FAST NO FUNCTION THUNDER STROBE NO FUNCTION RANDOM STROBE
<b>7</b>	0 - 255	<b>ZOOM</b>
<b>8</b>	000 – 010 011 – 100 101 – 110 111 – 120 121 – 150 151 – 160 161 – 170 171 – 180 181 – 190 191 – 200 201 – 210 211 – 220 221 – 255	<b>CONTROL ( execute after 3 sec. )</b> NO FUNCTION RESERVED DIMMER OFF DIMMER DIM4 RESERVED 1200Hz 2400Hz 4000Hz 6000Hz 25000Hz ALL RESET ZOOM RESET RESERVED

## TOUR ( 12 Kanal )

DMX Kanal	Wert	Funktion
<b>1</b>	000 – 255	<b>MASTER DIMMER</b>
<b>2</b>	000 – 255	<b>RED</b>
<b>3</b>	000 – 255	<b>GREEN</b>
<b>4</b>	000 – 255	<b>BLUE</b>
<b>5</b>	000 – 255	<b>WHITE</b>
<b>6</b>	000 – 010 011 – 255	<b>PRESET COLOR</b> NO FUNCTION PRESET COLORS ( SEE COLOR LIST )
<b>7</b>	000 – 009 010 - 024 025 - 039 040 - 054 055 - 069 070 - 084 085 - 099 100 - 114 115 - 129 130 - 144 145 - 159 160 - 174 175 - 189 190 - 204 205 - 245 255	<b>CCT</b> NO FUNCTION 1800K – 2199K 2200K – 2699K 2700K – 2999K 3000K – 3199K 3200K – 3999K 4000K – 4499K 4500K – 4999K 5000K – 5599K 5600K – 5999K 6000K – 6499K 6500K – 6999K 7000K – 7999K 8000K – 8999K 9000K – 9999K 10000K
<b>8</b>	000 – 009 010 – 099 100 – 109 110 – 179 180 – 189 190 – 255	<b>STROBE</b> NO FUNCTION STROBE SLOW TO FAST NO FUNCTION THUNDER STROBE NO FUNCTION RANDOM STROBE
<b>9</b>	000 – 040 041 – 050 051 – 060 061 – 070 071 – 080	<b>AUTO</b> NO FUNCTION AUTO 1 AUTO 2 AUTO 3 AUTO 4

	081 – 090	AUTO 5
	091 – 100	AUTO 6
	101 – 110	AUTO 7
	111 – 120	AUTO 8
	121 – 130	AUTO 9
	131 – 140	AUTO 10
	141 – 150	PROGRAM 1
	151 – 160	PROGRAM 2
	161 – 255	NO FUCTION
<b>10</b>	000 – 255	<b>AUTO SPEED ADJUSTMENT</b>
<b>11</b>	000 – 255	<b>ZOOM</b>
<b>12</b>		<b>CONTROL ( execute after 3 sec. )</b>
	000 – 010	NO FUNCTION
	011 – 100	RESERVED
	101 – 110	DIMMER OFF
	111 – 120	DIMMER DIM4
	121 – 150	RESERVED
	151 – 160	1200Hz
	161 – 170	2400Hz
	171 – 180	4000Hz
	181 – 190	6000Hz
	191 – 200	25000Hz
	201 – 210	ALL RESET
	211 – 220	ZOOM RESET
	221 – 255	RESERVED

### TR16 ( 17 Kanal )

DMX Kanal	Wert	Funktion
<b>1</b>	000 – 255	<b>MASTER DIMMER</b>
<b>2</b>	000 – 255	<b>MASTER DIMMER FINE</b>
<b>3</b>	000 – 255	<b>RED</b>
<b>4</b>	000 – 255	<b>RED FINE</b>
<b>5</b>	000 – 255	<b>GREEN</b>
<b>6</b>	000 – 255	<b>GREEN FINE</b>
<b>7</b>	000 – 255	<b>BLUE</b>
<b>8</b>	000 – 255	<b>BLUE FINE</b>
<b>9</b>	000 – 255	<b>WHITE</b>
<b>10</b>	000 – 255	<b>WHITE FINE</b>

<b>11</b>	000 – 010 011 – 255	<b>PRESET COLOR</b> NO FUNCTION PRESET COLORS ( SEE COLOR LIST )
<b>12</b>	000 – 009 010 - 024 025 - 039 040 - 054 055 - 069 070 - 084 085 - 099 100 - 114 115 - 129 130 - 144 145 - 159 160 - 174 175 - 189 190 - 204 205 - 245 255	<b>CCT</b> NO FUNCTION 1800K – 2199K 2200K – 2699K 2700K – 2999K 3000K – 3199K 3200K – 3999K 4000K – 4499K 4500K – 4999K 5000K – 5599K 5600K – 5999K 6000K – 6499K 6500K – 6999K 7000K – 7999K 8000K – 8999K 9000K – 9999K 10000K
<b>13</b>	000 – 009 010 – 099 100 – 109 110 – 179 180 – 189 190 – 255	<b>STROBE</b> NO FUNCTION STROBE SLOW TO FAST NO FUNCTION THUNDER STROBE NO FUNCTION RANDOM STROBE
<b>14</b>	000 – 040 041 – 050 051 – 060 061 – 070 071 – 080 081 – 090 091 – 100 101 – 110 111 – 120 121 – 130 131 – 140 141 – 150 151 – 160	<b>AUTO</b> NO FUNCTION AUTO 1 AUTO 2 AUTO 3 AUTO 4 AUTO 5 AUTO 6 AUTO 7 AUTO 8 AUTO 9 AUTO 10 PROGRAM 1 PROGRAM 2

	161 – 255	NO FUCTION
<b>15</b>	000 – 255	<b>AUTO SPEED ADJUSTMENT</b>
<b>16</b>	000 – 255	<b>ZOOM</b>
<b>17</b>		<b>CONTROL ( execute after 3 sec. )</b>
	000 – 010	NO FUNCTION
	011 – 100	RESERVED
	101 – 110	DIMMER OFF
	111 – 120	DIMMER DIM4
	121 – 150	RESERVED
	151 – 160	1200Hz
	161 – 170	2400Hz
	171 – 180	4000Hz
	181 – 190	6000Hz
	191 – 200	25000Hz
	201 – 210	ALL RESET
	211 – 220	ZOOM RESET
	221 – 255	RESERVED

Artikelnummer: led25120

TourLED MC120 MKII / 07.07.2021 FDR

Version V2.0.0 20210206



**PRESET COLOR LIST Tour LED MC 120 MKII**

<b>PRESET</b>	<b>WERT</b>	<b>NAME</b>	
	000 – 015	NO FUNCTION	
COLOR 1	016 – 020	R40	Light Salmon
COLOR 2	021 – 025	L24	Scarlet
COLOR 3	026 – 030	L164	Flame Red
	031 – 040	NO FUNCTION	
COLOR 4	041 – 045	L08	Dark Salmon
COLOR 5	046 – 050	L25	Sunset Red
	051 – 055	NO FUNCTION	
COLOR 6	056 – 060	L237	CID ( To Tungsten )
COLOR 7	061 – 065	R321	Soft Golden Amber
COLOR 8	066 – 070	L652	Urban Sodium
	071 – 075	NO FUNCTION	
COLOR 9	076 – 080	L765	LEE Yellow
COLOR 10	081 – 085	L117	Ice And A Slice
	086 – 105	NO FUNCTION	
COLOR 11	106 – 110	L90	Dark Yellow Green
	111 – 115	NO FUNCTION	
COLOR 12	116 – 120	R92	Tuiquoise
	121 – 135	NO FUNCTION	
COLOR 13	136 – 140	L728	Steel Green
COLOR 14	141 – 145	L117	Steel Blue
COLOR 15	146 – 150	L354	Special Steel Blue
	151 – 155	NO FUNCTION	
COLOR 17	156 – 160	L501	New Colour Blue
COLOR 18	161 – 165	L174	Dark Steel Blue
	166 – 180	NO FUNCTION	
COLOR 19	181 – 185	L142	Pale Violet
	186 – 195	NO FUNCTION	
COLOR 20	196 – 200	L794	Pretty'n Pink
COLOR 21	201 – 205	L328	Follies Pink
	206 – 215	NO FUNCTION	
COLOR 22	216 – 220	L127	Smokey Pink
COLOR 23	221 – 225	L192	Flesh Pink
	226 – 235	NO FUNCTION	
COLOR 24	236 – 240	L157	Pink
COLOR 25	241 – 245	R332	Cherry Rose
	246 – 255	NO FUNCTION	